User manual

Blueair

Scan here to access additional product, registration, warranty information and FAQs.

Blue Pure 411i+ Max

Safety information

Product name	Model number
Blue Pure 411i+ Max	32321111001

The energy efficiency of this ENERGY STAR certified model is based on the Integrated Energy Factor (IEF), a ratio between the model's PM2.5 CADR and its energy consumption, in terms of CADR/Watt.

Blue Pure 411i+ Max air purifier is electrical appliance for indoor use only. Take the necessary precautions to reduce the risk of fire, electric shock or injury.

WARNING: RISK OF ELECTRIC SHOCK – These servicing instructions are for use by qualified personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Supervise children to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Always disconnect the appliance from the power supply before maintenance.
- Do not attempt to open or service the appliance yourself, this can void your warranty. Service must be done by the manufacturer, service agent or similarly qualified personnel using only original Blueair spare parts.
- Ensure that the power cable and the power plug are not at risk of getting damaged. To avoid hazard, a damaged power cable must always be replaced by the manufacturer, service agent or similarly qualified person.
- If the appliance is damaged or malfunctions, turn it off, disconnect it from the power supply and contact Blueair.

- The power plug must be firmly inserted in the power socket.
- To reduce the risk of electric shock, this equipment has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet. Do not alter the plug in any way.
- When disconnecting the unit from the power supply, do not pull on the power cord, pull on the power plug.
- Use the power cable provided with your Blueair air purifier to plug directly and firmly into an appropriate, electrical outlet.
- Do not use an extension cord or a power strip. Refer to the rating label on your appliance.
- Do not alter the power plug in any way. If the plug does not fit into the outlet, contact qualified personnel to install the proper outlet.
- Do not use the included power cord for anything else but the appliance.
- Do not allow objects to enter or block the air inlets and air outlets as this can cause electric shock or damage the appliance.
- Do not place any objects on top of or directly against the appliance.
- Do not sit on, stand, climb onto or hang from the appliance.
- Keep the appliance, including the power cable, at a safe distance from heated surfaces and open fire.
- Keep the appliance and power plug away from water and other liquids.
- Keep the appliance and power plug away from chemicals such as pesticides and deodorants.
- Place the air purifier on the floor or a stable surface to prevent tipping.
- Do not use the appliance outdoors or in wet environments such as bathrooms, laundry rooms or pool areas.
- Always turn off and disconnect the appliance from the power supply before moving the unit, changing filters, cleaning or carrying out maintenance procedures.

- Never clean with gasoline, chemical solvents or corrosive materials as these agents may damage the air purifier.
- Do not wash the main filter, it's not washable or reusable.
- Wipe the top of the air purifier with a soft, clean cloth.
- Clean and check the power cable and power plug for wear or damages.
- Clean the pre-filters by washing in the washing machine or vacuum on low setting with a soft brush attachment (not included).
- This product complies with the maximum allowable concentration of ozone of 0.050 parts per million by volume (ppmv) in a 24-hour period.
- Do not allow foreign objects to enter the air inlets or air outlets. This may cause electric shock or damage the air purifier.

Regulatory information

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC/ISED RF Exposure Information: This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Product map

- A User interface
- B Air outlet
- C Air quality indicator (AQI)
- D Fan motor
- E Noise shield
- F Particle & carbon filter
- G Washable fabric pre-filter

Air quality status (PM 2.5)

The air purifier has a particle sensor to measure the fine particles (PM2.5) level. The LED indicator displays air quality status in 5 colors from excellent (blue) to very polluted (red).







Getting started

1. ON/Standby button
2. Fan Speed button

Indicators

3. Auto mode
4. Night mode (lowest speed setting)
5. Speed 1
6. Speed 2
7. Speed 3
8. Filter replacement
9. Wi-Fi





Two button control

Press the **ON/Standby button** to turn the air purifier.
Adjust the mode and the fan speed using the **Fan Speed button**.
This air purifier has a total of four fan speeds - **Night mode** being the lowest/most silent one, Speed three being the highest one.

Auto mode

Automatically adjusts the fan speed based on your PM2.5 indoor level to ensure optimal air quality.
Recommended setting.

Night mode

Lowest fan speed and fully dimmed lights.

1,2,3

Fan speeds 1–2–3

Fan speed levels which you can manually set by pressing the Fan Speed button on the interface or adjust via Blueair app.

How to use tips

Change brightness

Press the Fan Speed button and On/Standby button at the same time. Hold for three seconds.

Then, keep holding your finger on the On/Standby button and tap the Fan Speed button with the other finger to adjust brightness.

If the brightness is on the lowest level, then it will increase by one level. If the brightness is on the highest level, then it will decrease by one level.

Step 1



Step 2



Wi-Fi Pairing

If you want to connect your air purifier, hold Fan Speed button for 5 seconds until Wi-Fi LED starts blinking. Then follow the instructions in the "Connect to the Blueair APP" section.
If you choose not to connect the product, the Wi-Fi can be turned off. Long press Fan Speed button for about 5 seconds and then release.



5 seconds

Enable/disable Child lock

Long press On/Standby button for about 5 seconds (until all the LEDs of the interface light up and blink once). Then release.

When the Child lock is on the air purifier will continue to operate but the speed/mode button will be locked.



5 seconds

Filter reset

Extra long press Fan Speed button for about 15 seconds (until all the LEDs of the interface light up). Then release.

After replacing the filter, it is required to manually conduct filter reset on the appliance. If done correctly, the red filter replacement indicator will blink three times and then disappear.



15 seconds

Factory reset

Extra long press On/Stanby button for about 15 seconds (until all the LEDs of the interface light up for the second time and blink four times). Then release.

After factory reset, the air purifier restarts with default configuration will go into Standby mode.



15 seconds

Connect to the Blueair app

Connecting to the Blueair app allows you to control the air purifier remotely and monitor filter usage. The app offers additional functions to the air purifier.

Step 1

Download the Blueair app from the App store or Google play.

Step 2

Open the app. Create or sign into your Blueair account.

Step 3

Click on **Connect Product** and select **Blue**. Follow the instructions to complete app pairing.

First time connection tips

Make sure to turn on your air purifier. Once the Wi-Fi indicator is blinking, it is ready to be paired with your app.



Bluetooth is required for first time pairing. Turn your phone's bluetooth on and keep your phone within 3ft of the air purifier for initial pairing.



Keep your air purifier within 15 feet of your Wi-Fi router to maintain optimal connection.



Make sure you are using a visible Wi-Fi network that is not hidden.
VPN (Virtual Private Network) should be deactivated while using the Blueair App.



This air purifier can only connect to 2.4 GHz Wi-Fi.
If you are using a dual-band Wi-Fi router, make sure to select 2.4GHz.



Get the app


GET IT ON Google Play

Available on the App Store

Maintenance information

Important! Turn the air purifier off and disconnect the air purifier from the power supply before maintenance.


Changing your filter



When your air purifier's indicator light turns red, it's time to change the main filter. This will occur some time between 6 and 9 months of operation, depending on usage and your air quality conditions.

Step 1

Turn off the air purifier and unplug it. Rotate the top counter-clockwise to unlock, then lift up to remove it.




Step 2

Remove the fabric pre-filter and the noise shield.




Step 3

Use the filter handles to pull out the old filter and replace with new. Make sure to remove plastic wrapping before inserting the new filter in the appliance.



Step 4

Place the noise shield back on top of the filter. Pull up the the fabric pre-filter over the filter and the noise shield. (Please ensure that the leather tag is on the upper side of the fabric pre-filter.)



Step 5

Twist the top back on and plug in the air purifier.



Step 6

Important! Turn the air purifier back on and reset the filter indicator by pressing down the Fan Speed button for 15 seconds. (until all the LEDs of the interface light up for the second time and blink once). Then release.




Cleaning your washable pre-filter

Clean your pre-filter regularly when you see dust or dirt. Vacuum the exterior of the fabric with a soft brush attachment. If the pre-filter requires a deeper clean, wash according to the instructions on the pre-filter´s label. Hang to dry.

Step 1

Turn the air purifier off and unplug it. Rotate the top counter-clockwise to unlock and remove it.



Step 2

Remove the fabric pre-filter from the noise shield and main filter.



Step 3

Wash according to instructions on the fabric pre-filter´s label.



Step 4

Pull the clean pre-filter back over the noise shield and main filter.



Step 5

Please ensure that the leather tab of the pre-filter is on the upper part.



Step 6

Push the top cylinder down, rotate it clockwise to lock it.



Disposal and recycling

This air purifier should be recycled as electronic waste. If you have any questions regarding the disposal of this air purifier, please contact your local waste management for best way to recycle.

Troubleshooting

Issue	Potential Cause	Try this
There is a red circle on my air purifier's panel.	It is time to change the main filter.	1. Change filter according to the instructions in this guide. 2. Reset the filter life timer: press down the fan speed button until the red light disappears (15 seconds).
My air purifier is making too much noise.	Air purifiers that are set on a high-speed level produce more noise because they function at faster rates.	Set a lower fan speed. The air purifier should be quieter.
	The plastic sealing is still on the filter.	1. Remove the main filter according to the instructions in this guide. 2. Make sure that the plastic cover is removed from the filter.
	If the main filter or pre-filter are clogged or dirty, the engine might not get sufficient airflow, which may result in increased noise levels.	Unplug your air purifier and vacuum the air purifier and its fabric pre-filter from the outside with a soft brush attachment. Clean the fabric pre-filter in the washing machine. Replace the main filter when your filter indicator turns red.
I cannot connect my air purifier.	The air purifier is too far from your phone and router during the set up.	1. Ensure that your phone, air purifier and Wi-Fi router are in the same room and in close distance during initial set up (follow the app for exact distance instructions). Once you have successfully paired your air purifier you can place it at your desired location. 2.Make sure that your air purifier is plugged in and powered on.
	The Blueair App is not up to date.	Open your App Store in your phone and ensure you have the latest Blueair app version.
	The router is not on or has no connection. The router is not using a standard connection.	Ensure the following before trying to connect your product again: 1. Internet is currently running 2. You are using a 2.4Ghz network. 3. Deactivate VPN.
	Bluetooth is deactivated.	Ensure Bluetooth is enabled in your smartphone's settings.
My air purifier has lost connection.	Temporary Wi-Fi disturbances. New Wi-Fi settings or router.	If your air purifier does not re-connect by itself after a few minutes: 1. Open the Blueair app. 2. Select your air purifier and go to Product Settings. 3. Delete the air purifier. 4. Go back to the home screen and select "Connect Product". Follow the connection instructions on the product.
My indoor air quality is not improving.	Indoor air quality is polluted. Air quality sensors are dusty and showing incorrect levels.	1.Disconnect the power cable from the wall outlet and wait approximately 30 seconds 2. Make sure that there are no objects or dust around the air quality sensors at the back of the air purifier. 3. Reconnect the power cable. 4. Press the power button If the air quality does not improve with the use of the air purifier and with ventilation, please contact us.

For more information and troubleshooting tips, please check the Support page on **www.blueair.com**

Consignes de sécurité

Nom du produit	Numéro de modèle
Blue Pure 411i+ Max	32321111001

L'efficacité énergétique de ce modèle, certifié ENERGY STAR, est mesurée à partir du rapport entre son CADR pour la fumée et sa consommation d'énergie électrique, ou CADR/Watt.
Les purificateurs d'air Blue Pure 411i Max étant des appareils électriques destinés à être utilisés uniquement à l'intérieur, prenez les précautions nécessaires pour réduire le risque d'incendie, de choc électrique ou de blessure.
AVERTISSEMENT: RISQUE DE CHOC ÉLECTRIQUE - Ces instructions d'entretien sont destinées à être utilisées uniquement par du personnel qualifié. Pour réduire le risque de choc électrique, n'effectuez aucun entretien autre que celui contenu dans les instructions d'utilisation, sauf si vous êtes qualifié pour le faire.

- Cet appareil n'est pas conçu pour être utilisé par des personnes (notamment des enfants) dont les facultés physiques, sensorielles ou mentales sont réduites ou qui manquent d'expérience et de compétences, à moins qu'elles n'aient été supervisées ou formées à l'utilisation de l'appareil par une personne responsable de leur sécurité.
- Surveillez les enfants pour vous assurer qu'ils ne jouent pas avec l'appareil.
- Le nettoyage et l'entretien par l'utilisateur ne doivent pas être effectués par un enfant non supervisé.
- Débranchez toujours l'appareil de l'alimentation électrique avant de procéder à l'entretien.
- N'essayez pas d'ouvrir ou d'entretenir l'appareil vous-même, ceci pourrait annuler la garantie.
- L'entretien doit être effectué par le fabricant, l'agent de maintenance ou une personne disposant d'une qualification similaire en utilisant uniquement des pièces de rechange Blueair d'origine.
- Assurez-vous que le câble d'alimentation et la fiche d'alimentation ne risquent pas d'être endommagés. Pour éviter tout risque, un câble d'alimentation endommagé doit toujours être remplacé par le fabricant, l'agent de maintenance ou une personne disposant d'une qualification similaire.
- Si l'appareil est endommagé ou fonctionne mal, mettez-le hors tension, débranchez-le et contactez Blueair.

- La fiche d'alimentation doit être fermement insérée dans la prise de courant.
- Afin de réduire le risque de choc électrique, cet appareil est équipé d'une fiche polarisée dont une broche est plus large que l'autre. Cette fiche ne peut être insérée que dans un seul sens dans une prise polarisée. Si la fiche ne s'insère pas complètement, l'inverser.
- Si elle ne s'insère toujours pas, contacter un personnel qualifié pour installer une prise appropriée. Ne modifier la fiche en aucun cas.
- Lors du débranchement, ne pas tirer sur le câble d'alimentation, mais sur la fiche.
- Utiliser le câble d'alimentation fourni avec le purificateur d'air Blueair et le brancher directement et solidement dans une prise appropriée.
- Ne pas utiliser de rallonge ni de multiprise. Se référer à l'étiquette signalétique de l'appareil.
- Ne modifier la fiche d'alimentation en aucun cas. Si elle ne s'insère pas dans la prise, contacter un personnel qualifié pour installer une prise appropriée.
- Ne pas utiliser le câble d'alimentation fourni pour autre chose que cet appareil.
- Ne pas laisser d'objets pénétrer dans les entrées ou sorties d'air ni les obstruer, car cela pourrait provoquer un choc électrique ou endommager l'appareil.
- Ne pas placer d'objets sur ou directement contre l'appareil.
- Ne pas s'asseoir sur l'appareil, ne pas s'y tenir debout, ne pas y grimper ni s'y suspendre.
- Garder l'appareil, y compris le câble d'alimentation, à une distance sécuritaire des surfaces chaudes et des flammes nues.
- Garder l'appareil et la fiche d'alimentation à l'écart de l'eau et d'autres liquides.
- Garder l'appareil et la fiche d'alimentation à l'écart des produits chimiques tels que les pesticides et les désodorisants.
- Placer le purificateur d'air sur le sol ou sur une surface stable pour éviter tout basculement.
- Ne pas utiliser l'appareil à l'extérieur ni dans des environnements humides tels que les salles de bain, buanderies ou zones de piscine.
- Toujours éteindre et débrancher l'appareil avant de le déplacer, de changer les filtres, de le nettoyer ou d'effectuer un entretien.
- Ne jamais nettoyer avec de l'essence, des solvants chimiques ou des matériaux corrosifs, car ils peuvent endommager le purificateur d'air.
- N'introduisez pas d'objets étrangers dans les entrées ou les sorties d'air.

- Cela pourrait provoquer un choc électrique ou endommager le purificateur d'air.
- Ne nettoyez jamais avec de l'essence, des solvants chimiques ou des matériaux corrosifs, car ces agents peuvent endommager le purificateur d'air.
  Ne lavez pas le filtre principal, il n'est ni lavable ni réutilisable.
- Essuyez le dessus du purificateur d'air avec un chiffon doux et propre.
- Nettoyez et vérifiez le câble d'alimentation et la prise pour détecter toute usure ou tout dommage.
- Nettoyez les préfiltres en les lavant en machine ou en les aspirant à faible puissance avec un embout brosse douce (non inclus).
- Ce produit est conforme à la concentration maximale admissible d'ozone de 0,050 partie par million en volume (ppmv) sur une période de 24 heures.
- Ne laissez aucun objet étranger pénétrer dans les entrées ou sorties d'air. Cela pourrait provoquer un choc électrique ou endommager le purificateur d'air.

Informations réglementaires

AVERTISSEMENT : Toute modification apportée à cet appareil sans l'approbation expresse de la partie responsable de la conformité peut annuler le droit de l'utilisateur à l'utiliser.
REMARQUE : Cet équipement a été testé et déclaré conforme aux limites applicables aux appareils numériques de classe B, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour assurer une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement produit, utilise et peut émettre de l'énergie de radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions, il peut causer des interférences nuisibles aux communications radio. Cependant, aucune garantie ne peut être donnée quant à l'absence d'interférences dans une installation particulière. Si cet équipement cause des interférences nuisibles à la réception radio ou télévisuelle, ce qui peut être déterminé en allumant et en éteignant l'équipement, l'utilisateur est encouragé à tenter de corriger ces interférences par une ou plusieurs des mesures suivantes :

- Réorienter ou déplacer l'antenne de réception.
- Augmenter la distance entre l'équipement et le récepteur.
- Brancher l'équipement sur une prise d'un circuit différent de celui auquel le récepteur est connecté.
- Consulter le détaillant ou un technicien radio/télé expérimenté pour obtenir de l'aide.

Cet appareil est conforme à la partie 15 des règles de la FCC. Son fonctionnement est soumis aux deux conditions suivantes :

- Cet appareil ne doit pas causer d'interférences nuisibles.
- Cet appareil doit accepter toute interférence reçue, y compris celles pouvant entraîner un fonctionnement indésirable.

Cet appareil numérique de classe B est conforme à la norme canadienne ICES-003.

Cet appareil contient des émetteurs/récepteurs exempts de licence conformes aux normes RSS exemptes de licence d'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférences, et (2) cet appareil doit accepter toute interférence, y compris celles pouvant entraîner un fonctionnement indésirable.

Informations sur l'exposition RF FCC/ISED : Cet équipement doit être installé et utilisé en respectant une distance minimale de 20 centimètres entre le radiateur et votre corps.

Plan du produit

- A Interface utilisateur
- B Sortie d’air
- C Indicateur de la qualité de l’air
- D Moteur de ventilateur
- E Silencieux
- F Filtre à particules et à charbon
- G Pré-filtre en tissu lavable

État de la qualité de l’air (PM 2.5)

Le purificateur d’air a un capteur de particules pour mesurer le niveau de particules fines (PM 2.5). L’indicateur LED affiche l’état de la qualité de l’air en 5 couleurs allant d’excellent (bleu) à très pollué (rouge).







Démarrer

1. Bouton Marche/Veille
2. Bouton de vitesse du flux d'air

Indicateurs

3. Mode automatique
4. Mode nuit (vitesse la plus basse)
5. Vitesse 1
6. Vitesse 2
7. Vitesse 3
8. Remplacement du filtre
9. Wi-Fi





Commande à deux boutons

Appuyez sur le bouton **Marche/Veille** pour allumer le purificateur d'air.
Réglez le mode et la vitesse du débit d'air à l'aide du bouton de **vitesse du flux d'air**.
Ce purificateur d'air a un total de quatre vitesses de ventilateur - le **Mode nuit** étant la plus basse et plus silencieuse, la vitesse trois étant la plus élevée.

Mode automatique

Ajuste automatiquement la vitesse du ventilateur à partir de votre niveau intérieur de PM2,5 pour garantir une qualité d'air optimal. Paramètre recommandé.

Mode nuit

Vitesses du flux d'air la plus basse et lumières entièrement tamisées.

1,2,3

Vitesses du flux d'air 1–2–3

Niveaux de vitesse du flux d'air que vous pouvez définir manuellement en appuyant sur le bouton de vitesse du flux d'air sur l'interface ou en réglant la vitesse via l'application Blueair.

Astuces d'utilisation

Modifier la luminosité

Appuyez sur le bouton de bouton de vitesse du flux d'air et sur le bouton de Marche/ Veille en même temps. Maintenez pendant trois secondes.

Ensuite, continuez à tenir votre doigt sur le bouton Marche/Veille et appuyez sur le bouton de bouton de vitesse du flux d'air avec l'autre doigt pour régler la luminosité.

Si la luminosité est au niveau le plus bas, alors il augmentera d'un niveau. Si la la luminosité est au plus haut niveau, alors il diminuera d'un niveau.

L'appairage Wi-Fi

Si vous souhaitez connecter votre purificateur d'air, maintenez le bouton Vitesse de ventilation pendant 5 secondes jusqu'à ce que le voyant Wi-Fi clignote. Suivez ensuite les instructions de la rubrique "Connexion à l'application Blueair". Si vous ne souhaitez pas connecter l'appareil, vous pouvez désactiver le Wi-Fi. Maintenez longuement le bouton Vitesse de ventilation environ 5 secondes, puis relâchez-le.

1ère étape



2ème étape





5 secondes

Activer/désactiver la sécurité enfant

Appuyez longuement sur le bouton Marche/Veille pendant environ 5 secondes (jusqu'à ce que toutes les LEDs de l'interface s'allument et clignotent une fois). Puis, relâchez.

Lorsque la sécurité enfant est activée, le purificateur continue à fonctionner mais le bouton vitesse/mode verrouillé.



5 secondes

Indicateur de remplacement du filtre

Appuyez longuement sur le bouton de vitesse du flux d'air pendant environ 15 secondes (jusqu'à ce que toutes les LEDs de l'interface s'allument). Puis, relâchez.

Après avoir remplacé le filtre, il est nécessaire d'effectuer manuellement la réinitialisation de l'indicateur de remplacement du filtre. Une fois la réinitialisation effectuée, l'indicateur rouge de remplacement du filtre clignote trois fois puis disparait.



15 secondes

Réinitialisation de votre appareil

Appuyez longuement sur le bouton Marche/Veille pendant environ 15 secondes (jusqu'à ce que Les LEDs de l'interface s'allument pendant la deuxième fois et clignote quatre fois). Puis, relâchez.

Après avoir réinitialiser l'appareil, le purificateur d'air redémarre avec la configuration par défaut et passe en mode veille.



15 secondes

Connectez-vous à l'application Blueair

La connexion à l'application Blueair vous permet de contrôler le purificateur d'air à distance et de surveiller l'état de l'utilisation du filtre. L'application propose des fonctions supplémentaires à utiliser avec votre purificateur.

1ère étape

Téléchargez l'application Blueair depuis l'App Store ou Google Play.

2ème étape

Ouvrez l'application. Créez un compte ou connectez-vous à votre compte Blueair.

3ème étape

Cliquez sur **Connecter le Produit** et sélectionnez **Blue**. Suivez les instructions pour compléter la connection à l'application.

Conseils pour la première connexion

Assurez-vous d'allumer votre purificateur d'air. Une fois que l'indicateur Wi-Fi clignote, il est prêt à être jumelé avec votre application.



La fonction Bluetooth est necessaire pour le première connection. Activez la fonction Bluetooth sur votre téléphone et gardez votre téléphone à moins de 3 pieds du purificateur d'air pendant la première connection.



Gardez votre purificateur d'air à moins de 15 pieds de votre routeur Wi-Fi pour maintenir une connection optimal.



Assurez-vous que vous utilisez un réseau Wi-Fi visible (réseau qui n'est pas caché). Tout VPN (réseau virtuel privé) doit être désactivé lors de l'utilisation l'application Blueair.



Ce purificateur d'air peut se connecter uniquement à un réseau 2.4 Wi-Fi GHz. Si vous utilisez un router mixte (2.4 et 5 Ghz), assurez-vous de sélectionnez le réseau 2,4 GHz.



Obtenir l'application


GET IT ON Google Play

Available on the App Store

Informations d'entretien

Important! Éteignez le purificateur d'air et débranchez-le de l'alimentation électrique avant l'entretien.


Changer votre filtre



Lorsque le voyant de votre purificateur d'air devient rouge, il est temps de changer le filtre principal. Cela se produit après 6 à 9 mois de fonctionnement, selon l'utilisation et les conditions de la qualité de l'air.

Étape 1

Éteignez le purificateur d'air et débranchez-le. Tourner le haut dans le sens inverse des aiguilles d'une montre pour déverrouiller, puis soulever pour le retirer.




Étape 2

Retirer le pré-filtre en tissu et le silencieux.




Étape 3

Utilisez les poignées du filtre pour sortir l'ancien filtre et le remplacer avec un nouveau. Assurez-vous d'enlever le plastique d'emballage du nouveau filtre avant insertion dans l'appareil.



Étape 4

Placer le silencieux au dessus de filtre. Tirez le le pré-filtre en tissu sur le filtre et le silencieux. (Assurez-vous que l'étiquette en cuir soit sur le côté extérieur du pré-filtre en tissu).



Étape 5

Refermez le purificateur en tournant le haut du cylindre dans le sens des aiguilles d'une montre. Branchez le purificateur.



Étape 6

Important! Allumez le purificateur d'air et réinitialiser l'indicateur du filtre en appuyant sur le bouton de vitesse du flux de l'air pendant 15 secondes. (jusqu'à ce que toutes les LEDs de l'interface s'allument pour la deuxième fois et clignotent une fois). Puis, relâchez.




Nettoyage de votre pré-filtre

Nettoyez régulièrement votre pré-filtre lorsque vous voyez de la poussière ou de la saleté. Aspirez l'extérieur du tissu avec la brosse douce de votre aspirateur. Si le pré-filtre nécessite un nettoyage en profondeur, lavez-le conformément aux instructions figurant sur l'étiquette du pré-filtre. Suspendre pour sécher.

Étape 1

Éteignez le purificateur d'air et débranchez-le. Tourner le haut dans le sens inverse des aiguilles d'une montre pour déverrouiller, puis soulever pour le retirer.



Étape 2

Retirer le pré-filtre en tissu et le silencieux.



Étape 3

Lavez conformément aux instructions figurant sur l'étiquette du pré-filtre.




Étape 4

Disposez le pré-filtre propre autour du silencieux and du filtre principal.




Étape 5

Assurez-vous que l'étiquette en cuir soit sur le côté extérieur du pré-filtre en tissu.



Étape 6

Poussez le haut du cylindre vers le bas et tournez-le dans le sens des aiguilles d'une montre pour refermer le purificateur.



Élimination et recyclage

Ce purificateur d'air doit être recyclé en tant que déchet électronique. Si vous avez des questions concernant l'élimination de ce purificateur d'air, veuillez contacter les autorités locales ou votre revendeur Blueair et demander la méthode de recyclage correcte.

Blueair

www.blueair.com

Blueair Inc.
200 N LaSalle St,
Suite 2800,
Chicago, IL 60601 USA

